

Polycarbon wind direction transmitter (Model 485)



Table of contents

Chapter 1 introduction



- 1.1 product overview
- 1.2 functional features
- 1.3 main parameters
- 1.4 system diagram
- Chapter 2 hardware connectivity
 - 2.1 equipment pre-installation inspection
 - 2.2
 - 2.2.1 sensor wiring
 - 2.3
 - 2.4 precautions
- Chapter 3 configuration software installation and use
 - 3.1 the sensors are connected to the computer
 - 3.2 use of sensor monitoring software
- Chapter 4 communication protocols
 - 4.1 basic communication parameters
 - 4.2 data frame format definition
 - 4.3 register address
 - 4.4 numeric values correspond to conversion relationships
 - 4.5 examples and explanations of communication protocols
- Chapter 5 common problems and solutions

Chapter 1 product introduction

1.1 product overview

The wind direction sensor is compact and light in appearance, easy to carry and assemble, the three-cup design concept can effectively obtain external environmental information, the shell is made of polycarbonate composite material, and the exterior is treated by electroplating and plastic spraying, it has good anti-corrosion, anti-corrosion and other characteristics, can ensure the long-term use of the instrument without rust, and with the internal smooth bearing system to ensure the accuracy of information collection. It is widely used in greenhouse, environmental protection, weather stations, ships, docks, aquaculture and other environmental wind direction measurement.

1.2 functional characteristics

Range: 8 directions

Anti-electromagnetic interference treatment

Adopt high-performance imported bearings, small rotational resistance, accurate



measurement

Polycarbonate shell, mechanical strength, high hardness, corrosion resistance, non-rust can be used outdoors for a long time

The structure and weight of the equipment are carefully designed and distributed, with small moment of inertia and sensitive response


Standard Modbus-rtu communication protocol, easy access

1.3 main parameters


DC power supply (default)	10-30 V DC
Power consumption	≤ 0.15 W
Transmitter circuit operating temperature	-40 ° C ~ + 60 ° C, 0% RH ~ 80% Rh
Communication interface	485 communication (Modbus) protocol Baud rate: 2,400,4,800(default) , 9,600 Data bit length: 8 bits Parity: None Stop bit length: 1 bit Default Modbus address: 1 Support function code: 03
Parameter setting	Configure with the provided configuration software through the 485 interface
Measurement range	Eight directions
Dynamic response speed	≤ 0.5 s

Shell dimensions






整体高度：160
 主轴高度：144
 底座高度：71
 底座直径：φ80
 单位 (mm)



安装孔径：φ4.5
 分布直径：φ68
 单位 (mm)

1.4 system framework diagram

单接




The product can also be used in a combination of multiple sensors in a 485 bus,



in theory a bus can be 254485 sensors, the other end with a 485 interface PLC, 485 interface chip connected with the MCU, or use USB to 485 can be connected to the computer, the use of my company's sensor configuration tools for configuration and testing (use the configuration software can only be connected to one device) .

多接



Chapter 2 hardware connectivity

2.1 equipment pre-installation inspection

Equipment list:

- || transmitter equipment 1
- || install 4 screws
- || Certificate of Conformity and Warranty Card

2.2

Wide voltage input 10-30V. 485 signal line wiring attention to a B two lines can not be connected back, the bus address between multiple devices can not conflict.



2.2.1 sensor wiring




	Color	Description
电 源	Brown	Power supply positive (10 ~ 30V DC)
	Black	The power supply is negative
通 信	Yellow (green)	485-A
	Blue	485-B

2.3 installation

The lower pipe of the wind direction sensor is firmly fixed on the flange plate by means of flange installation and threaded flange connection. The chassis $\varnothing 80\text{mm}$ is provided with four mounting holes of $\varnothing 4.5\text{ mm}$ in the circumference of the $\varnothing 68\text{mm}$, use Bolts to fasten it on the bracket, so that the whole set of instruments, to maintain the best level, to ensure the accuracy of wind direction data, flange connection easy to use, can withstand greater pressure.



注意：
安装时，让传感器上的**箭头**
冲着正北方，以免造成测量
误差。



2.4 precautions

1. Users are not allowed to disassemble or touch the sensor core to prevent damage to the product.
2. As far as possible away from high-power interference equipment, so as not to cause inaccurate measurement, such as inverter, motor, etc. .
3. To prevent chemical reagents, oil, dust and other direct damage to the sensor, do



not dew, limit temperature environment for long-term use, prevent cold and heat shock.


Chapter 3 configuration software installation and use

We provide the supporting“485 parameter configuration software”, can easily use the computer to read the parameters of the sensor, while flexible modification of the sensor device ID and address.

Note that when using software for automatic access, you need to ensure that there is only one sensor on the 485 bus.

3.1 the sensor is connected to the computer

After connecting the sensor to the 485 via USB and powering it properly, you can see the correct COM port on your computer (see the COM port in my pc-properties-device manager-port) .



Open the package, select“Debugging software”-“485 parameter configuration software”, find to open.

If you do not find a COM port in device manager, it means that you do not have a USB to 485 driver installed (in the package) or you do not have the driver installed correctly, please contact a technical person for help.

3.2 use of sensor monitoring software


Configuration interface as shown in the figure, first according to Section 3.1 method to get the serial port number and select the correct serial port.

Click on the test baud rate of the software, the software will test the current device baud rate and address, the default baud rate is 4800 bit/s, the default address is 0x01.

3. Change the address and baud rate as needed, and query the current function status of the device.

If the test is not successful, please re-check the equipment wiring and 485 driver installation.





Chapter 4 communication protocols

4.1 basic communication parameters

Coding	8-bit binary
Data bits	Eight
Parity bit	无
Stop bit	1 bit
Error checking	CRC (redundant cyclic code)
Baud rate	2400 bit/s, 4800 bit/s, 9600 bit/s can be set, the factory default is 4800 bit/s

4.2 data frame format definition

Using the ModBus-RTU protocol, the format is as follows:

Initial structure ≥ 4 bytes in time

Address code = 1 byte

Function code = 1 byte

Data area = N bytes

Error Check = 16-bit CRC code



Time to end structure ≥ 4 bytes

Address Code: the address of the transmitter, in the communication network is unique (factory default 0x01) .

Function code: this transmitter only uses the function code 0x03(reads register data) .

Data area: Data area is specific communication data, note that 16bits data high byte in front!

CRC code: two-byte checksum code.

Host query frame structure:

Address Code	Function codes	Register start address	Register length	Low checksum	High checksum
1 byte	1 byte	2 bytes	2 bytes	1 byte	1 byte

Slave response frame structure:

Address Code	Function codes	The number of valid bytes	Data Area 1	The second data area	N data area	Check Code
1 byte	1 byte	1 byte	2 bytes	2 bytes	2 bytes	2 bytes

4.3 register address

Register address	PLC or configuration address	Content	Operation
000h	40001	Wind direction (0-7 Gear) Uploading the data is the true value	Read only
001h	40002	Wind direction (0-360 °) Uploading the data is the true value	Read only

4.4 numeric values correspond to conversion relationships

Collection values (0-7 files)	Acquisition Values (0-360 °)	Direction
0	0 °	North Wind



1	45 degrees	A northeasterly wind
2	90 degrees	East Wind
3	135 degrees	Southeast wind
4	180 °	South wind
5	225 degrees	Southwest wind
6	270 degrees	West Wind
7	315 degrees	Northwest wind

4.5 communication protocol examples and explanations

Example: wind direction reading device address 0x01

Query frame:

Address Code	Function codes	Starting address	Data Length	Low checksum	High checksum
0x01	0x03	0x000x00	0x000x02	0xC4	0x0B

Response Frame: (for example, read wind direction value (0-7 stops) is 2, (0-360 °) is 90 °)

Address Code	Function codes	Returns the number of valid bytes	Wind direction (0-7 Gear)	Wind direction (0-360 °)	Low checksum	High checksum
0x01	0x03	0x04	0x000x02	0x000x5a	0xDB	0xC8

Wind direction:

(range 0-7) : 0002H (hexadecimal) = 2 => wind direction = easterly

(0-360 °) : 005AH -LRB-hexadecimal) = 90 => wind direction = East Wind

Chapter 5 common problems and solutions

No output or output errors

Possible reasons:

1. The computer has a com port and the port chosen is incorrect.
2. Baud rate error.



The 485 bus is disconnected, or the A and B wires are switched back.

4. If the number of equipment is too large or the wiring is too long, the local power supply should be added with 485 enhancer and 120Ω terminal resistance.

The USB 485 drive is not installed or damaged.

6. Equipment damage.

